




























MONTAGEANLEITUNG  
 INSTRUCTIONS DE MONTAGE  
 ASSEMBLY INSTRUCTIONS  
 MONTAGEAANWIJZING



# 980304





150	3		371	1		6x60
159	3		377	2		4x25
187	4		503	1		
190	8	 Ø8x30	737	4		
201	2		741	1		8x51
220	6		742	1		
320	8		844	0-1		264 mm
351	8	 3,5x15	845	0-1		364 mm
352	4	 4x20	847	0-1		414 mm
370	2	 4x15	848	0-1		464 mm

